


# **LASER EFFECT**



Manuale Utente User Manual Music & Lights S.r.l. si riserva ogni diritto di elaborazione in qualsiasi forma delle presenti istruzioni per l'uso. La riproduzione - anche parziale - per propri scopi commerciali è vietata. Al fine di migliorare la qualità dei prodotti, la Music&Lights S.r.l. si riserva la facoltà di modificare, in qualunque momento e senza preavviso, le specifiche menzionate nel presente manuale di istruzioni. Tutte le revisioni e gli aggiornamenti sono disponibili nella sezione 'Manuali' sul sito www.musiclights.it

# Sicurezza Avvertenze generali 4 Descrizione Installazione 2. 1 Montaggio ...... 10 Funzioni e impostazioni 3 3. 1 Funzionamento 3. 2 Impostazione base \_\_\_\_\_\_11 3. 5 Impostazione iniziale 12 3. 10 Tabella canali DMX Manutenzione

# Contenuto dell'imballo:

**INDICE** 

- WIZARD
- Cavo di alimentazione

Certificato di garanzia

- Chiavi (per safety switch) (2 p.zi)
- Staffa di fissaggio
- Manuale utente



ATTENZIONE! Prima di effettuare qualsiasi operazione con l'unità, leggere con attenzione questo manuale e conservarlo accuratamente per riferimenti futuri. Contiene informazioni importanti riguardo l'installazione, l'uso e la manutenzione dell'unità.



# **SICUREZZA**

### Avvertenze generali

- I prodotti a cui questo manuale si riferisce sono conformi alle Direttive della Comunità Europea e pertanto recano la sigla c€.
- Il dispositivo funziona con pericolosa tensione di rete 230V~. Non intervenire mai al suo interno al di fuori delle operazioni descritte nel presente manuale; esiste il pericolo di una scarica elettrica.
- È obbligatorio effettuare il collegamento ad un impianto di alimentazione dotato di un'efficiente messa a terra (apparecchio di Classe I secondo norma EN 60598-1). Si raccomanda, inoltre, di proteggere le linee di alimentazione delle unità dai contatti indiretti e/o cortocircuiti verso massa tramite l'uso di interruttori differenziali opportunamente dimensionati.
- Le operazioni di collegamento alla rete di distribuzione dell'energia elettrica devono essere effettuate da un installatore elettrico qualificato. Verificare che frequenza e tensione della rete corrispondono alla frequenza ed alla tensione per cui l'unità è predisposta, indicate sulla targhetta dei dati elettrici.
- L'unità non per uso domestico, solo per uso professionale.
- Evitare di utilizzare l'unità:
  - in luoghi soggetti a vibrazioni, o a possibili urti;
  - in luoghi a temperatura superiore ai 40°C o inferiore a 10°.
- Evitare che nell'unità penetrino liquidi infiammabili, acqua o oggetti metallici.
- Non smontare e non apportare modifiche all'unità.
- Tutti gli interventi devono essere sempre e solo effettuati da personale tecnico qualificato. Rivolgersi al più vicino centro di assistenza tecnica autorizzato.
- Se si desidera eliminare il dispositivo definitivamente, consegnarlo per lo smaltimento ad un'istituzione locale per il riciclaggio.




#### Attenzioni e precauzioni per l'installazione

- Questo prodotto è solo per uso interno. Per prevenire il rischio di incendi o scosse elettriche, non esporre il prodotto alla pioggia o all'umidità.
- Questo prodotto non è destinato ad installazioni permanenti.
- Assicurarsi che il dispositivo sia spento (che l'interruttore sia posizionato su off) prima di collegare il dispositivo alla rete di alimentazione.
- Se il dispositivo dovesse trovarsi ad operare in condizioni differenti da quelle descritte nel presente manuale, potrebbero verificarsi dei danni; in tal caso la garanzia verrebbe a decadere. Inoltre, ogni altra operazione potrebbe provocare cortocircuiti, incendi, scosse elettriche, rotture etc.
- Prima di iniziare qualsiasi operazione di manutenzione o pulizia disconnettere l'unità dalla rete di alimentazione.
- Non scuotere il dispositivo. Evitare la forza bruta quando si monta o si utilizza il prodotto.
- Per l'installazione in sospensione è assolutamente necessario proteggere l'unità per mezzo di una fune di sicurezza. Nell'eseguire qualsiasi intervento attenersi scrupolosamente a tutte le normative (in materia di sicurezza) vigenti nel paese di utilizzo.
- Installare l'unità in un luogo ben ventilato. La distanza minima tra il dispositivo e le pareti circostanti deve essere superiore a 50cm e non devono essere ostruite, in nessun caso, le aperture d'aerazione.
- Mantenere materiali infiammabili ad una distanza di sicurezza dall'unità.
- Non guardare direttamente il fascio luminoso. Tenere presente che i veloci cambi di luce possono provocare attacchi d'epilessia presso persone fotosensibili o epilettiche.

### Sicurezza laser e istruzioni operative

- Non utilizzare il proiettore laser senza lettura e comprensione sulla sicurezza laser e sulle istruzioni
  operative contenute in questo manuale.
- Secondo la norma EN 60825-1:2007, questo prodotto appartiene alla classe 4. Il contatto diretto con gli occhi può provocare lesioni.
- Il raggio laser può causare danni permanenti agli occhi ed alla pelle.
- · Non dirigere il raggio laser su persone o animali.
- Non dirigere il raggio laser su superfici altamente riflettenti come finestre, specchi e metalli lucidi. Anche la riflessione del laser può essere pericolosa.
- · Non guardare mai l'apertura laser o i raggi laser.
- Non sottoporre l'uscita ottica (apertura), ai prodotti chimici di pulizia.
- Non utilizzare il proiettore laser se il corpo di alloggiamento è danneggiato o aperto, o se l'ottica appare in qualche modo danneggiata.
- Non aprire mai l'alloggiamento del laser. I livelli di potenza del laser possono provocare lesioni alla pelle e agli occhi.
- Dopo il set-up, e prima di utilizzo in pubblico, testare il laser per garantirne il corretto funzionamento.
- Non lasciare mai il dispositivo in esecuzione automatica.
- Il funzionamento di un laser show di questo tipo è consentito solo se lo spettacolo è controllata da un operatore esperto e ben addestrato, con conoscenza dei dati inclusi in questo manuale.
- I requisiti legali per l'utilizzo di prodotti laser di intrattenimento variano da paese a paese. L'utente è
  responsabile per i requisiti di legge nella paese di utilizzo.
- Secondo le norme internazionali di sicurezza, il proiettore laser deve essere installato in modo che il raggio laser presenta una distanza minima di 3 m dal pavimento se, sotto il raggio, si trattengono delle persone. Tuttavia, il dispositivo può essere installato anche in modo che il raggio laser, in senso orizzontale, sia ad una distanza minima di 2,5 m dalle persone.




### **IMPORTANTE**

- L'unità deve essere installata in modo tale da escludere che si possa guardare direttamente nel raggio laser. Anche una breve esposizione può provocare dei danni permanenti agli organi visivi. Si devono evitare riflessi involontari.
- Il funzionamento di un laser di classe 4 è consentito solo se controllato da un operatore qualificato.
- Per impedire l'utilizzo non autorizzato servirsi dell'interruttore a chiave.

I dispositivi laser con radiazioni accessibili recano etichette in modo da indicare:

- il segnale d'avvertimento laser;
- la classe di appartenenza del dispositivo laser unitamente all'indicazione cautelativa e di avvertimento pertinente, nonché
- · i dati di identificazione e i dati del tipo.



LASER DATA	WIZARD
Laser Classification	Class 4
Red	638nm 120mW
Green	DPSS 532nm 100mW
Blue	450nm 600mW
Angle (scanner)	1-36°
Speed	20K

#### **INFORMAZIONI GENERALI**

#### Spedizioni e reclami

Le merci sono vendute "franco nostra sede" e viaggiano sempre a rischio e pericolo del distributore/cliente. Eventuali avarie e danni dovranno essere contestati al vettore. Ogni reclamo per imballi manomessi dovrà essere inoltrato entro 8 giorni dal ricevimento della merce.

#### Garanzie e resi


Il prodotto è coperto da garanzia in base alle vigenti normative. Sul sito www.musiclights.it è possibile consultare il testo integrale delle "Condizioni Generali di Garanzia". Si prega, dopo l'acquisto, di procedere alla registrazione del prodotto sul sito www.musiclights.it. In alternativa il prodotto può essere registrato compilando e inviando il modulo riportato alla fine del manuale. A tutti gli effetti la validità della garanzia è avallata unicamente dalla presentazione del certificato di garanzia. Music & Lights constata tramite verifica sui resi la difettosità dichiarata, correlata all'appropriato utilizzo, e l'effettiva validità della garanzia; provvede quindi alla riparazione dei prodotti, declinando tuttavia ogni obbligo di risarcimento per danni diretti o indiretti eventualmente derivanti dalla difettosità.

# -1- DESCRIZIONE

# 1.1 SPECIFICHE TECNICHE


LIGHT SOURCE	
Red	638nm 120mw
Green	DPSS 532nm 100mw
Blue	450nm 600mw
Туре	Class 4 laser
SCANNER	
Angle	1-36°
Speed	20K
WORKING CONDITION	
Maximum External Temp	40°C
INTERNAL CONTROLLER	
Auto	Two laser effects
Sound	Two laser effects
EXTERNAL CONTROLLER	
I/Q Connectors	(DMX) 3-pin XLR/(ILDA) DB25
S/D Connectors	Outlay SD card store programs
Channel Range	1-24
POWER	
Range	100-240V 50/60Hz
Consumption	26W
Fuse	T1.6A 250V
Dimensions and weight	
Dimensions (WxHxD)	316x150x254mm
Weight	3,75kg

#### 1.2 ELEMENTI DI COMANDO E DI COLLEGAMENTO



Vista frontale Fig.1

- 1. APERTURA RAGGIO LASER quando la scansione laser è compresa tra  $\pm 1^\circ$ , il raggio laser si spegnerà automaticamente.
- 2. INDICATORE DI FUNZIONAMENTO quando il LED rosso è acceso, il dispositivo è in funzione.
- INDICATORE DEL SEGNALE MUSICALE il LED si accende se il microfono rileva un segnale musicale di volume sufficiente per comandare il raggio laser.
- 4. SAFETY EYE per l'aggancio al cavo di sicurezza
- MANOPOLA DI FISSAGGIO per la staffa di montaggio.
- 6. STAFFA DI MONTAGGIO



Vista Posteriore Fig.2

- 7. PRESA DI VENTILAZIONE apertura per uscita flusso d'aria da non ostruire
- 8. ILDA INPUT: Ingresso standard ILDA DB25, per il controllo del dispositivo tramite PC.
- 9. ILDA OUTPUT: Uscita standard ILDA DB2.
- 10. SD MEMORY CARD: memorizzazione e riproduzione dei programmi
- 11. GND POINT usato per la messa a terra del dispositivo.
- 12. POWER IN spina da pannello VDE per il collegamento ad una presa di rete (100-240~/50-60Hz) tramite il cavo di rete in dotazione. Accanto la spina si trova il portafusibile. Sostituire un fusibile difettoso solo con uno dello stesso tipo.

- 13. INTERRUTTORE ON/OFF
- 14. DMX IN (XLR 3 poli): 1 = massa, 2 = DMX -, 3 = DMX +
- 15. DMX OUT (XLR 3 poli): 1 = massa, 2 = DMX -, 3 = DMX +
- 16. DISPLAY multi informazione per l'interfaccia utente-macchina
- 17. POTENZIOMETRO A SCATTI MULTIFUNZIONE per accesso e gestione delle diverse funzioni
- 18. POTENZIOMETRO DI REGOLAZIONE per le dimensioni dei pattern (5-100%)
- SAFETY SWITCH per attivare/disattivare il raggio laser (diodo laser). Per ragioni di sicurezza assicurarsi che la chiave sia utilizzata solo dall'operatore autorizzato.

### - 2 - INSTALLAZIONE

#### 2.1 MONTAGGIO

Il WIZARD può essere collocato su un piano solido. Inoltre, grazie alle possibilità di fissaggio sulla staffa (fig.3), l'unità può essere montata con versatilità su una traversa. Per il fissaggio occorrono dei supporti robusti per il montaggio. L'area di collocazione deve avere una stabilità sufficiente e supportare almeno 10 volte il peso dell'unità.

Inoltre, assicurarsi di rispettare tutte le avvertenze, in materia di sicurezza, per i dispositivi a raggio laser.

- Fissare il proiettore laser attraverso l'apposita staffa (6) ad una collocazione idonea.
- È assolutamente necessario assicurare il proiettore laser contro la caduta utilizzando un cavo di sicurezza: in particolare collegare il cavo in un punto adatto in modo che la caduta del proiettore non possa superare i 20 cm.
- Orientare il proiettore laser intervenendo, se necessario, sulla manopola della staffa di montaggio (5). ATTENZIONE! L'installazione deve essere effettuata solo da personale qualificato. Un'installazione non corretta può causare gravi lesioni e danni alle cose.




Fig.3

### - 3 - FUNZIONI E IMPOSTAZIONI

#### 3.1 FUNZIONAMENTO

Inserire la spina del cavo di alimentazione in una presa di rete (230V~ 50Hz). Accendere il WIZARD, con l'interruttore (13). Per azionare il raggio laser, inserire la chiave in dotazione nella serratura relativa (19) e girare la chiave in posizione ON. Quando il laser è acceso, il display LCD (16), sul pannello posteriore, mostra l'ultima modalità di funzionamento confermata con il tasto ENTER.


L'unità può essere comandata da un unità DMX di comando luce oppure svolgere autonomamente il suo programma.

ATTENZIONE - Il funzionamento di un laser di classe 4 è consentito solo se controllato da un operatore qualificato.


- Il proiettore laser non è progettato per un utilizzo continuato. Al fine di ottimizzare la vita del dispositivo effettuare regolari pause durante il funzionamento.
- Non accendere e spegnere l'unità in brevi intervalli di tempo.
- Disconnettere l'unità quando non è utilizzata per lunghi periodi di tempo.
- In caso di gravi problemi di funzionamento, smettere di usare il dispositivo e contattare immediatamente un centro di assistenza tecnica autorizzato.

#### 3.2 IMPOSTAZIONE BASE

Il WIZARD dispone di un display LCD e diversi controlli per accesso e gestione delle funzioni del menu (fiq.5).



### 3.3 INDICAZIONI DISPLAY



# 3.4 IMPOSTAZIONE DELLA LINGUA

OPERAZIONE	ISTRUZIONI
25	Tenere premuto il cursore mentre si preme l'interruttore di accensione
$(\bigcirc)$	Ruotare il cursore per selezionare la lingua desiderata
	Premere per confermare

# **3.5 IMPOSTAZIONE INIZIALE**


OPERAZIONE	ISTRUZIONI
	Premere l'interruttore di accensione e ruotare il cursore per poter accedere alle seguenti funzioni
$(\bigcirc)$	Monochrome - RGY - Seven Color - Max Speed - LCD setup - Version
	Dopo selezionare la voce Exit e premere sul cursore per confermare

# 3.6 DESCRIZIONE FUNZIONI

MODALITÀ	OPERAZIONE	ISTRUZIONI
ILD mode		
Play List		Ruotare il cursore per muoversi nel menu di selezione e premere per confermare la scelta.
Built-in effects		NOTA - Automaticamente dopo 8 secondi verrà confer- mata la scelta selezionata
DMX		
Sound control		Modalità musicale
Quit	25	Tenere premuto per 2 secondi per tornare al menu principale o ritornare al livello precedente

#### 3.7 MODIFICA DELLA PLAY LIST SULLA SD CARD

Nella modalità "ILD mode", selezionare il documento ILD che si desidera modificare e premere il cursore per inserire il file nella SD list. Far riferimento alla seguente procedura:



Tempo di riproduzione del file ILD

Mode:ILD 20K
Add To List?
Yes No

Lista SD di default

Mode:ILD 20K
Remove List ?
Yes No

Rimuovere o meno la lista precedentemente compilata; riavviare per editare una nuova lista

### 3.8 IMPOSTAZIONE PATTERN

X mirror	The horizontal direction of the pattern flip	
Y mirror	Figure vertical direction flip	
Color setting	single red green yellow RGB	Commodible with the initial catting
Scanning speed	0-30K to choose scanner speed	Compatible with the initial setting
Play speed	The rate change of the pattern speed, the larger the numerical value, the slower the playback speed	Effective only in the ILD play mode

# 3.9 MODALITÀ DMX

Diverse modalità di funzionamento sono state pre-impostate al canale DMX 1. Prima della gestione degli altri canali DMX, assicurarsi di impostare al canale 1 la modalità di funzionamento desiderata.

СН	Function	Value
1	Laser Block Out	000
	ILD show in SD card	001 - 040
	LIST show in SD card	041 - 080
	ILD show in SD card by sound control	081 - 100
	LIST show in SD card by sound control	101 - 120
	AUTO SHOW	121 - 160
	MUSIC SHOW	161 - 200
	DMX MODE	201 - 240
	DMX MODE by sound control	241 - 255

# ILD mode or Play list

СН	ILD mode or Play list	Value
2	Sound sensitivity control	000 - 255
3	No function	
4	Select the SD card folder	000 - 255
5	ILD file folder or play the file LST	000 - 255

# **3.10 TABELLA CANALI DMX**

Channel	Function	Value
CH2	Sound sensitivity control	000 - 255
CH3/CH14	Laser Block Out	
	Pattern out through the mode, Channel value of 1-6, the pattern will shrink	001 - 049
	Pattern out of bounds foldback mode, Channel value of 51-56, the pattern will be reduced	050 - 099
Pattern mode selection	Pattern out through the mode, Channel value of 101-106, the pattern will shrink	100 - 149
	Pattern out of bounds foldback mode, Channel value of 151-156, the pattern will shrink	150 - 199
	The pattern out of bounds reentrant mode, Channel value 201-206, 251-256, the pattern will shrink	200 - 255
CH3/CH14 Pattern mode  Total 128 patterns, each 2 value becomes into 1 pattern		000 - 255
	Adjust the size of the pattern manually	000 - 063
	Zoom back and forth the 32th value as section, into 3 section effect	064 - 191
CH5/CH16 Shrinking	Shrinking	160 - 192
	Enlarge	192 - 223
	Zoom back and forth (largest to smallest)	224 - 255
	Adjust the angle of rotation manually	000 - 063
CH6/CH17	Rotating back and forth the 32th value as a section, into 4 section effect	064 - 191
Rotating	Clockwise rotation	192 - 223
	Counterclockwise rotation	224 - 255
CH7/CH18	Manually adjust the horizontal movement of Location	000 - 063
Horizontal	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255

Channel	Function	Value
CH8/CH19	Manually adjust the horizontal shrinking movement of Location	000 - 063
Vertical movement	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH9/CH20	Manually adjust the horizontal shrinking movement of Location	000 - 063
Horizontal shrinking	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH10/CH21	Manually adjust the horizontal shrinking movement of Location	000 - 063
Vertical shrinking	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH11/CH22	Adjust gradually drawn position manually	000 - 063
Gradually drawn	Adjust the speed of gradually drawn	064 - 255
CH12/CH23 Node	The nattern node clarity adjusting	
	Primary	000 - 007
	Red	008 - 015
	Green	016 - 023
	Yellow	024 - 031
	Blue	032 - 039
CH13/CH24 Colour	Purple	040 - 047
	Cyan	048 -055
	White	056 - 063
	Current discoloration	064 -127
	Monochrome transition	128 -191
	Blending transition	192 - 255

### -4- MANUTENZIONE

#### **4.1 MANUTENZIONE E PULIZIA DISPOSITIVO**

- Durante gli interventi, assicurarsi che l'area sotto il luogo di installazione sia libera da personale non qualificato.
- Spegnere l'unità, scollegare il cavo di alimentazione ed aspettare finché l'unità non si sia raffreddata.
- Tutte le viti utilizzate per l'installazione dell'unità e le sue parti devono essere assicurate saldamente e non devono essere corrose.
- Alloggiamenti, elementi di fissaggio e di installazione (soffitto, truss, sospensioni) devono essere totalmente esenti da qualsiasi deformazione.
- I cavi di alimentazione devono essere in condizione impeccabile e devono essere sostituiti immediatamente nel momento in cui anche un piccolo problema viene rilevato.
- Si dovrebbe procedere, ad intervalli regolari, alla pulizia della parte frontale per asportare polvere, fumo e altre particelle. Solo così, la luce può essere irradiata con la luminosità massima. Per la pulizia usare un panno morbido, pulito e un detergente per vetri come si trovano in commercio. Quindi asciugare le parti delicatamente.

Attenzione: consigliamo che la pulizia interna sia eseguita da personale qualificato!

#### **4.2 RISOLUZIONE DEI PROBLEMI**

Anomalie	Controlli e rimedi
II dispositivo non funziona	<ul> <li>Verificare la presenza della tensione alimentazione</li> <li>Controllare il cavo di alimentazione</li> <li>Controllare che sia acceso il relativo indicatore LED</li> </ul>
ll dispositivo è alimentato ma il laser non viene fuori dall'apertura	<ul> <li>Verificare che l'apertura laser non sia coperta</li> <li>Controllare l'interruttore a chiave</li> </ul>
II laser è debole	<ul><li>Pulire lo specchio dello scanner con l'alcol</li><li>Pulire l'apertura di vetro con l'alcol</li></ul>
II dispositivo non risponde al DMX	<ul> <li>Controllare il pannello di controllo e l'indirizzamento delle unità</li> <li>Controllare il cavo di segnale DMX</li> <li>Controllare l'interruttore di polarità sul controller</li> <li>Sostituire DMX input</li> </ul>

Rivolgersi a un centro di assistenza tecnico autorizzato in caso di problema non riportato in tabella o che non possono essere risolti mediante la procedura riportata in tabella.

All rights reserved by Music & Lights S.r.l. No part of this instruction manual may be reproduced in any form or by any means for any commercial use. In order to improve the quality of products, Music&Lights S.r.l. reserves the right to modify the characteristics stated in this instruction manual at any time and without prior notice. All revisions and updates are available in the 'manuals' section on site www.musiclights.it

# **TABLE OF CONTENTS**

General instructions	2
Warnings and installation precautions	2
aser safety and operating instructions	
General information	4
I Dossvintion	
Description	_
1.1 Technical specifications	
1.2 Operating elements and connections	6
2 Installation	
2.1 Mounting	8
B Functions and settings	
3.1 Operation	۵
3. 2 Basic	
3. 3 The main interface function description	
3. 4 Language setting	
3. 5 Basic setting	
3. 6 Play function description	
3. 7 Edit SD playing list	
3. 8 Pattern setting	
3. 9 DMX channel chart	
3. 10 DMX control	1
Maintenance	
1. 1 Maintenance and cleaning the unit	1
1. 2 Trouble shooting	

# Warranty

# **Packing content**

- WIZARD
- Power cable
- Keys (for safety switch) (2 pcs)
- Mounting bracket
- User manual



WARNING! Before carrying out any operations with the unit, carefully read this instruction manual and keep it with cure for future reference. It contains important information about the installation, usage and maintenance of the unit.



# **SAFETY**

#### **General instruction**

- The products referred to in this manual conform to the European Community Directives and are therefore marked with c∈.
- The unit is supplied with hazardous network voltage (230V~). Leave servicing to skilled personnel only.
   Never make any modifications on the unit not described in this instruction manual, otherwise you will risk an electric shock.
- Connection must be made to a power supply system fitted with efficient earthing (Class I appliance according to standard EN 60598-1). It is, moreover, recommended to protect the supply lines of the units from indirect contact and/or shorting to earth by using appropriately sized residual current devices.
- The connection to the main network of electric distribution must be carried out by a qualified electrical
  installer. Check that the main frequency and voltage correspond to those for which the unit is designed
  as given on the electrical data label.
- This unit is not for home use, only professional applications.
  - Never use the fixture under the following conditions:
    - in places subject to vibrations or bumps;
    - in places with a temperature of over 40°C or less than 10°C.
  - Make certain that no inflammable liquids, water or metal objects enter the fixture.
- · Do not dismantle or modify the fixture.
- All work must always be carried out by qualified technical personnel. Contact the nearest sales point for an inspection or contact the manufacturer directly.
- If the unit is to be put out of operation definitively, take it to a local recycling plant for a disposal which is not harmful to the environment.




### Warnings and installation precautions

- The unit for indoor use only. To prevent or reduce the risk of electrical shock or fire, do not expose the
  unit to rain or moisture.
- This product is not intended for permanent installation.
- Make sure that the power-switch is set to off-position before you connect the device to the mains.
- If this device will be operated in any way different to the one described in this manual, it may suffer
  damage and the guarantee becomes void. Furthermore, any other operation may lead to dangers like
  short circuit, burns, electric shock, etc.
- Before starting any maintenance work or cleaning the unit, cut off power from the main supply.
- Do not shake the device. Avoid brute force when mounting or operating the product.
- Always additionally secure the device with the safety rope. When carrying out any work, always comply
  scrupulously with all the regulations (particularly regarding safety) currently in force in the country in
  which the fixture's being used.
- Install the fixture in a well ventilated place. The minimum distance between the fixture and surrounding walls must be more than 50 cm and the air vents at the housing must not be covered in any case.
- Keep any inflammable material at a safe distance from the fixture.
- Never look directly at the light beam. Please note that fast changes in lighting, e. g. flashing light, may trigger epileptic seizures in photosensitive persons or persons with epilepsy.

# Laser safety and operating instructions

- Do not operate laser without first reading and understanding all safety and technical data in this manual.
- According to EN 60825-1:2007, this product belongs to class 4. Direct eye contact may cause injury.
- This laser product can potentially cause instant eye injury or blindness if laser light directly strikes the eyes.
- Do not point lasers at people or animals.
- Do not point lasers at highly reflective surfaces such as windows, mirrors and shiny metal. Even laser reflections can be hazardous.
- · Never look into the laser aperture or laser beams.
- Do not expose the output optic (aperture) to cleaning chemicals.
- Do not use laser if housing is damaged or open, or if optics appear damaged in any way.
- Never open the laser housing. The high laser power levels inside of the protective housing can start fires, burn skin and will cause instant eye injury.
- After set up, and prior to public use, test laser to ensure proper function.
- Never leave this device running unattended.
- The operation of a class 4 laser show is only allowed if the show is controlled by a skilled and welltrained operator, familiar with the data included in this manual.
- The legal requirements for using laser entertainment products vary from country to country. The user is responsible for the legal requirements at the location/country of use.
- According to international safety regulations the laser must be installed so that the laser beam has a
  minimum distance of 3 m to the floor when persons stand or sit under the beam. However, the unit
  can also be installed so that in the horizontal plane the laser beam keeps a minimum distance of 2.5 m
  to persons.




#### **IMPORTANT**

The unit must be installed so that nobody will be able to look directly into the laser beam. Already a short radiation on the retina may cause permanent damage. Unintentional reflections must be prevented. The laser system must not be operated without the presence of a laser protection adviser. In case of absence, this advisor should have secured the laser beam with the key switch against unauthorized operation.

#### LASER SAFETY LABEL REPRODUCTIONS

- Class 4 laser radiation, when open, avoid exposure to beam.
- Laser radiation avoid exposure to beam class 4 laser product.
- The label indicates the laser beam output aperture.



LASER DATA	WIZARD
Laser Classification	Class 4
Red	638nm 120mW
Green	DPSS 532nm 100mW
Blue	450nm 600mW
Angle (scanner)	1-36°
Speed	20K

#### **GENERAL INFORMATION**

#### Shipments and claims

The goods are sold "ex works" and always travel at the risk and danger of the distributor. Eventual damage will have to be claimed to the freight forwarder. Any claim for broken packs will have to be forwarded within 8 days from the reception of the goods.

#### Warranty and returns


The guarantee covers the fixture in compliance with existing regulations. You can find the full version of the "General Guarantee Conditions" on our web site www.musiclights.it. Please remember to register the piece of equipment soon after you purchase it, logging on www.musiclights.it. The product can be also registered filling in and sending the form available on your guarantee certificate. For all purposes, the validity of the guarantee is endorsed solely on presentation of the guarantee certificate. Music & Lights will verify the validity of the claim through examination of the defect in relation to proper use and the actual validity of the guarantee. Music & Lights will eventually provide replacement or repair of the products declining, however, any obligation of compensation for direct or indirect damage resulting from faultiness.

# -1- DESCRIPTION

# 1.1 TECHNICAL SPECIFICATIONS


Red 638nm 120mw Green DPSS 532nm 100mw  Blue 450nm 600mw  Type Class 4 laser  SCANNER  Angle 1-36° Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Type Class 4 laser  SCANNER  Angle 1-36° Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Type Class 4 laser  SCANNER  Angle 1-36°  Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
SCANNER  Angle 1-36° Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Angle 1-36°  Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Speed 20K  WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
WORKING CONDITION  Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Maximum External Temp 40°C  INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
INTERNAL CONTROLLER  Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Auto Two laser effects  Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
Sound Two laser effects  EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
EXTERNAL CONTROLLER  I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
I/Q Connectors (DMX) 3-pin XLR/(ILDA) DB25  S/D Connectors Outlay SD card store programs  Channel Range 1-24  POWER
S/D Connectors Outlay SD card store programs Channel Range 1-24 POWER
Channel Range 1-24 POWER
POWER
<b>Range</b> 100-240V 50/60Hz
Consumption 26W
<b>Fuse</b> T1.6A 250V
Dimensions and weight
Dimensions (WxHxD) 316x150x254mm
Weight 3,75kg

#### 1.2 OPERATING ELEMENTS AND CONNECTIONS



Front view Fig.1

- 1. LASER APERTURE when the laser scanning pattern within  $\pm 1^{\circ}$ , will shut off laser automatically
- 2. POWER INDICATOR LED red light when the machine is turned
- SOUND INDICATOR LED voice signal indicator flashes with the change of the received sound signal
- 4. SAFETY EYE to attach safety cable
- 5. LOCKING KNOB for the mounting bracket
- 6. MOUNTING BRACKET



Rear view Fig.2

- 7. VENTILATION OPENINGS: the openings let the air flow in. Do not obstruct them
- 8. ILDA INPUT standard ILDA interface, inside the machine ILDA signal automatic device automatically switch between internal program and ILDA program.
- ILDA OUTPUT standard ILDA interface, the output signal gain unlited coupling. Playback control box as SD program output can be used as SD card ILDA to control with other laser has ILDA interface.
- 10. SD memory card laser program storage and playback, compatible with the TF, SD card
- 11. GND POINT grounding the fixture to the earth
- 12. POWER IN mains plug for connection to a socket (100-240V~/50-60Hz) via the supplied mains cable. The support for the mains fuse is

located near the mains plug. Only replace a blown fuse by one of the same type.

- 13. ON/OFF POWER SWITCH
- 14. DMX IN (3-pole XLR): 1 = ground, 2 = DMX -, 3 = DMX +
- 15. DMX OUT (3-pole XLR):1 = ground, 2 = DMX -, 3 = DMX +
- 16. MULTI-INFORMATION DISPLAY man-machine interface, to control menu display
- 17. THE SHUTTLE BUTTON menu control buttons, up and down to select, confirm, exit etc functions
- 18. ADJUSTMENT KEYS adjustment of pattern size (5%-100% between adjustment)
- SAFETY SWITCH to turn the laser effect (laser diode) ON/OFF. Be sure that only authorized operator hold the key.

### - 2 - INSTALLATION

### 2.1 MOUNTING

WIZARD may be set up on a solid and even surface. The unit can also be mounted upside down to a cross arm. For fixing, stable mounting clips are required. The mounting place must be of sufficient stability and be able to support a weight of 10 times of the unit's weight.

The legal requirements for using laser entertainment products vary from country to country. The user is responsible for the legal requirements at the location/country of use.

The unit must be installed so that nobody will be able to look directly into the laser beam. Already a short radiation on the retina may cause permanent damage. Unintentional reflections must be prevented.

- Install the projector at a suitable location by means of the mounting bracket (6).
- Always additionally secure the projector with the safety rope from falling down. For this purpose, fasten the safety rope at a suitable position so that the maximum fall of the projector will be 20 cm.
- Adjust the projector and use the knob (5) to slightly release or tighten the locking mechanism of the bracket if is necessary.

ATTENTION! The installation must be carried out by qualified service personal only. Improper installation can result in serious injuries and/or damage to property.




Fig.3

# - 3 - FUNCTIONS AND SETTINGS

### 3.1 OPERATION


Connect the supplied main cable to a socket  $(230 \, \text{V} \sim /50 \, \text{Hz})$ . Switch on the WIZARD with the mains switch (13). To switch on the laser beam, connect the supplied key to the lock of the switch (19) and turn the key to position ON. When laser is powered on, LCD monitor on rear panel shows the current operating mode. Then the unit is ready for operation and can be operated via a DMX controller or it independently performs its show program in succession.

WARNING - This laser corresponds to the class 4. Do not permit operation by persons not qualified for operating the device.


- Regular breaks during operation are essential to maximize the life of this device as it is not designed for continual use.
- Do not switch the unit on and off in short time intervals.
- Always unplug the unit when it is not used for a longer time.
- In the event of serious operation problems, stop using the fixture and contact the manufacturer directly.

#### 3.2 BASIC

Access control panel functions using the four panel buttons located directly underneath the LCD Display (fig.5).




## 3.3 THE MAIN INTERFACE FUNCTION DESCRIPTION



# 3.4 LANGUAGE SETTING

OPERATION	INSTRUCTION
25	Start-up, when the version information screen appears, press and hold 2 seconds
$(\bigcirc)$	Select the language
	Determine the selection, automatic exit into the boot

# 3.5 BASIC SETTING




# 3.6 PLAY FUNCTION DESCRIPTION

MODE SELECTION	OPERATION	INSTRUCTION		
ILD mode				
Play List		Select 8 seconds after jump automatically to the se		
Built-in effects		lected mode or opt-out jumped into the selected mode		
DMX				
Sound control		Sound control pattern change		
Quit	25	Back to the main menu and return to the previous level		

# 3.7 EDIT SD PLAYING LIST

In ILD mode, select the ILD document you want to edit, press inward (as below picture), file by file put into the SD list, as follows.



ILD file playback times

Mode:ILD 20K
Add To List?
Yes No

SD default list

Mode:ILD 20K
Remove List?
Yes No

Select No, previously compiled list will be added to the back, empty on the new list, re-start editing a new list

### 3.8 PATTERN SETTING

X mirror	The horizontal direction of the pattern flip	
Y mirror	Figure vertical direction flip	
Color setting	single red green yellow RGB	Commodible with the initial costs or
Scanning speed	0-30K to choose scanner speed	Compatible with the initial setting
Play speed	The rate change of the pattern speed, the larger the numerical value, the slower the playback speed	Effective only in the ILD play mode

# **3.9 DMX CHANNEL CHART**

Several optional operating modes were preprogrammed set into this laser projector at DMX channel1. Before control other DMX channels, please be sure that the channel 1 was set in proper mode (value).

СН	Function	Value
	Laser Block Out	000
	ILD show in SD card	001 - 040
	LIST show in SD card	041 - 080
	ILD show in SD card by sound control	081 - 100
1	LIST show in SD card by sound control	101 - 120
	AUTO SHOW	121 - 160
	MUSIC SHOW	161 - 200
	DMX MODE	201 - 240
	DMX MODE by sound control	241 - 255

# ILD mode or Play list

ILD mode or Play list	Value
Sound sensitivity control	000 - 255
No function	
Select the SD card folder	000 - 255
ILD file folder or play the file LST	000 - 255
	Sound sensitivity control  No function  Select the SD card folder

# 3.10 DMX CONTROL

Channel	Function	Value			
CH2	H2 Sound sensitivity control				
	Laser Block Out	000			
	Pattern out through the mode, Channel value of 1-6, the pattern will shrink	001 - 049			
CH3/CH14	Pattern out of bounds foldback mode, Channel value of 51-56, the pattern will be reduced	050 - 099			
Pattern mode selection	Pattern out through the mode, Channel value of 101-106, the pattern will shrink	100 - 149			
	Pattern out of bounds foldback mode, Channel value of 151-156, the pattern will shrink	150 - 199			
	The pattern out of bounds reentrant mode, Channel value 201-206, 251-256, the pattern will shrink	200 - 255			
CH3/CH14 Pattern mode	Total 128 patterns, each 2 value becomes into 1 pattern	000 - 255			
	Adjust the size of the pattern manually	000 - 063			
	Zoom back and forth the 32th value as section, into 3 section effect	064 - 191			
CH5/CH16 Shrinking	Shrinking	160 - 192			
	Enlarge	192 - 223			
	Zoom back and forth (largest to smallest)	224 - 255			
	Adjust the angle of rotation manually	000 - 063			
CH6/CH17 Rotating	Rotating back and forth the 32th value as a section, into 4 section effect	064 - 191			
	Clockwise rotation	192 - 223			
	Counterclockwise rotation	224 - 255			
CH7/CH18	Manually adjust the horizontal movement of Location	000 - 063			
Horizontal	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect				

Channel	Function	Value
CH8/CH19	Manually adjust the horizontal shrinking movement of Location	000 - 063
Vertical movement	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH9/CH20	Manually adjust the horizontal shrinking movement of Location	000 - 063
Horizontal shrinking	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH10/CH21	Manually adjust the horizontal shrinking movement of Location	000 - 063
Vertical shrinking	The effect of vertical shrinking movement the 32th value as a section, into 6 section effect	064 - 255
CH11/CH22	Adjust gradually drawn position manually	000 - 063
Gradually drawn	Adjust the speed of gradually drawn	064 - 255
CH12/CH23 Node	The pattern node clarity adjusting	000 - 255
	Primary	000 - 007
	Red	008 - 015
	Green	016 - 023
	Yellow	024 - 031
	Blue	032 - 039
CH13/CH24 Colour	Purple	040 - 047
	Cyan	048 -055
	White	056 - 063
	Current discoloration	064 -127
	Monochrome transition	128 -191
	Blending transition	192 - 255

### -4- MAINTENANCE

#### 4.1 MAINTENANCE AND CLEANING THE UNIT

- Make sure the area below the installation place is free from unwanted persons during setup.
- Switch off the unit, unplug the main cable and wait until the unit has cooled down.
- All screws used for installing the device and any of its parts should be tightly fastened and should not be corroded.
- Housings, fixations and installation spots (ceiling, trusses, suspensions) should be totally free from any deformation.
- The main cables must be in impeccable condition and should be replaced immediately even when a small problem is detected.
- The interior of the device should be cleaned annually using a vacuum cleaner or air-jet.
- It is recommended to clean the front at regular intervals, from impurities caused by dust, smoke, or other particles to ensure that the light is radiated at maximum brightness. For cleaning, disconnect the main plug from the socket. Use a soft, clean cloth moistened with a mild detergent. Then carefully wipe the part dry. For cleaning other housing parts use only a soft, clean cloth. Never use a liquid, it might penetrate the unit and cause damage to it.

Warning: we strongly recommend internal cleaning to be carried out by qualified personnel!

#### 4.2 TROUBLESHOOTING

Problems	Checks and remedies
The fixture does not work, no laser and the fan does not work	Check the connect power     Measure the mains voltage on the main connector     Check the power on indicated LED
The fixture is power on, but no laser coming out from aperture	Check the laser aperture cover     Check the key switch
The laser effect power is very weak	Clean the scanner mirror with alcohol Clean the aperture glass with alcohol
Fixture does not respond to DMX	<ul> <li>Check control panel and unit addressing</li> <li>Check DMX cables</li> <li>Check polarity switch settings on thecontroller</li> <li>Replace DMX input</li> </ul>

Contact an authorized service center in case of technical problems or not reported in the table can not be resolved by the procedure given in the table.



Place Stamp Here

Musice [][][]

X

**GUARANTEE CERTIFICATE** 

CERTIFICATO DI GARANZIA The guarantee covers the unit requlations. You can find the in compliance with existing full version of the "General

can be also registered filling in and sending the form available on your oiece of equipment soon after you Please remember to register the www.musiclights.it. The product Defects caused by inexperience **Guarantee Conditions" on our** General Guarantee Conditions web site www.musiclights.it. ourchase it, logging on Abstract

prodotto sul sito www.musiclights.it.

procedere alla registrazione del

Si prega, dopo l'acquisto, di

Condizioni Generali di Garanzia

Estratto dalle

In alternativa il prodotto può essere registrato compilando e inviando il

The guarantee will no longer be and incorrect handling of the equipment are excluded. guarantee certificate. seen tampered.

La garanzia non ha più alcun effetto

qualora l'apparecchio sia stato

imperizia e da uso non appropriato

dell'apparecchio.

Sono esclusi i quasti causati da

modulo riportato sul retro.

The guarantee makes no provision External parts, lamps, handles, effective if the equipment has or the replacement of the equipment.

esterne, le lampade, le manopole, gli

interruttori e le parti asportabili.

Sono escluse dalla garanzia le parti

sostituzione dell'apparecchio.

La garanzia non prevede la

manomesso.

Fransport costs and subsequent not included in the guarantee. isks are responsibility of the owner of the equipment.

switches and removable parts are

Spett.le

04020 Itri (LT) Italy

on presentation of the guarantee the guarantee is endorsed solely

or all purposes, the validity of

dalla presentazione del certificato di

garanzia è avallata unicamente

A tutti qli effetti la validità della

conseguenti sono a carico del

Le spese di trasporto e i rischi possessore dell'apparecchio.

Music&Lights S.r.l. Via Appia Km 136.200

Affrancare

Il prodotto è coperto da garanzia

in base alle vigenti normative.

Sul sito www.musiclights.it è

possibile consultare il testo

integrale delle "Condizioni

Generali di Garanzia".

×

Purchasing date  Data acquisto  FORM TO BE FILLED IN AND MAILED / CEDOLA DA COMPILARE E SPEDIRE	Timbro e firma del Rivenditore	Dealer's stamp and signature	ZIP CODE / C.A.P.	CITY/CITTA'	ADDRESS / VIA	NAME / NOME	SURNAME / COGNOME	Purchased by / Acquistato da	SERIAL N° / SERIE N°	MODEL / MODELLO
Purchasing date  Data acquisto  FORM TO BE FILLED IN AND KEPT / CEDOLA DA	Timbro e firma del Rivenditore	Dealer's stamp and signature	PROV. ZIP CODE / C.A.P.	CITY/CITTÀ	N. ADDRESS / VIA	NAME / NOME	SURNAME / COGNOME	Purchased by / Acquistato da	SERIAL N° / SERIE N°	MODEL / MODELLO
IND KEPT / CEDOLA DA COMPILARE E CONSERVARE			PROV.		z			istato da		





PROLIGHTS è un brand di proprietà della Music & Lights S.r.I.

**Music & Lights** S.r.l. entertainment technologies Via Appia km 136,200 - 04020 Itri (LT) ITALY ISO 9001:2008 ISO 9001:2008 Certified Company tel. +39 0771 72190 fax +39 0771 721955 www.musiclights.it info@musiclights.it